


MODEL
AD201CH



รายละเอียดสินค้า

รายละเอียดสินค้าทุกรุ่น	จ่ายน้ำร้อน น้ำเย็น
กำลังไฟ	220V-240V/50Hz
การกินไฟความเย็น	0.7 A
การกินไฟ ความร้อน	2.0 A
<u>ระบบความเย็น</u>	
คอมเพรสเซอร์ (วัตต์)	85 วัตต์
บ๊า呀	HFC-134 A
ระบบควบคุมความเย็น	เกอร์โนสตาร์ก
อุณหภูมิความเย็น	4 °c~10 °c
กังบรรจุน้ำเย็น	2.0 ลิตร
ระบบความร้อน	
การกินไฟ	420 วัตต์
ระบบทำความร้อน	Band Heater
ควบคุมความร้อน	Bi-metal 2 ตัว
อุณหภูมิความร้อน	80 °c~95 °c
กังบรรจุน้ำร้อน	5.0 ลิตร

ASTINA
PURE

Water Dispenser USE SPECIFICATION


Model:AD201CH

Please read the use specification carefully before you use this product, and let the use specification be well placed.

Character

- 1.Modern design.
 - 2.Energy-saving, low noise, resistant structure and great stability. Suitable for use in homes, hotels, schools, etc.
 - 3.The plastic parts of this product use high quality and durable plastic.
 - 4.Double security system, "temperature control" and "heating protection". Hot water temperature is always between 80 ° C and 95 ° C, enough to make coffee or tea, or other instant food.
 - 5.The water dispenser's cooling system is durable and suitable for use during the summer.
 - 6.This product can be used with bottled water or a water purifier.

Part name



NO.	NAME	NO.	NAME
1	Bottle Seat	6	Cold Water Faucet
2	Power Switch	7	Hot Water Faucet
3	Indicator Lights	8	Drip Tray
4	Information Plate	9	Electric Power Cord
5	Safety Push Button	10	Drain Plug

Note: The graphic is for reference only. The current device may have differences with the graphic.



Operation process

1. Insert the bottle vertically on the seat and press the water faucets until water flows out of the red hot water faucet.
 2. Insert the power plug to the wall socket and turn the electric switches to ON position to start the appliance. DO NOT MOVE BOTH SWITCHES AT THE TIME. Cooling and heating indicator lights should light up. The appliance is designed to provide hot or cold water whenever you need it. It will automatically turn on and off when the water reaches the desired temperatures.

การทำความสะอาด

- การทำความสะอาดภายนอกทำได้โดยใช้ผ้าชุบน้ำหมาดๆ หรือบ้ำข้าวทำความสะอาดแบบอ่อนๆ เนื้อบริเวณภายนอก เที่ยงส่วนเด้านี้ในที่สุดแล้วก็สามารถกรอกทำความสะอาดโดยใช้ผ้าข้าวทำความสะอาดหรือบ้ำข้าวเชือแบบอ่อนๆ ได้ ในส่วน พื้นที่ว่างในถังเก็บน้ำร้อน สำหรับรุ่นที่มีระบบหัวร้อน(บริเวณตรงล่วงบนกลางของถังเก็บน้ำเย็น) ไม่ควรใช้บ้ำข้าวเชือได้ มากทำความสะอาดในถังน้ำร้อนและระบบบ้ำข้าวเชือของโดยผ่านออกทางสายท่อน้ำเย็น แล้วใช้บ้ำข้าวเชือทำความสะอาดถังเก็บน้ำเย็นให้ทั่วทั่วทุก部分ใช้งาน
 - ในการทำความสะอาด ห้ามน้ำยาเครื่องมาแรง เช่นน้ำ หรือใช้น้ำล้างเดียวโดยเดียว
 - บริเวณแพลงระบายน้ำด้านล่าง ควรรักษาความสะอาดไม่ให้สกปรกมีฝุ่นเพื่อประสิทธิภาพในการใช้
 - หลังจากทำความสะอาดสะอาดแล้วก่อนเปิดสต็อกที่ทำงาน ควรทำให้เครื่องแห้งก่อนและควรทำการบรรจุใส่ถังน้ำให้เรียบร้อย

การป้องกันและการใช้งานอย่างปลอดภัย

<p>1. หลักเหลี่ยมการวางไกล์เติร์องทำน้ำร้อน และแสงอาทิตย์โดยตรง</p> 	<p>2. วางเดิร์องบนผู้ที่เรียบและมั่นคง</p> 
<p>3. เครื่องอาจเสียหายได้ และเป็นอันตราย ในกรณีเปิดน้ำร้อนทิ้งไว้โดยไม่มีน้ำในถังน้ำร้อน</p>	<p>4. ควรตั้งอุณหภูมิเบ้าเข็นไว้ที่ 4 องศาเซลเซียส และตั้งน้ำร้อนไว้ที่ 95 องศาเซลเซียส มิ เช่นนั้น อยู่กรุงโซลงานจะดังมาก สั่นลง ปกติโรงงานจะตั้งมา เรียบร้อยแล้ว ไม่ควรปรับแต่ง เพิ่มเติม</p> 
<p>5. ตรวจสอบระบบไฟฟ้า ปลั๊กไฟ ควรตั้งต่ำไฟมากกว่า 12 แอมป์</p>	
<p>6. ควรตั้งเครื่องห่างจากผนังอย่างน้อย 15 เซนติเมตร</p> 	<p>7. ไม่ควรวางเครื่องในจุดที่มีอุณหภูมินากกว่า 45 องศาเซลเซียส (C)</p> <p>8. เมื่อมีการย้ายที่ตั้งเครื่องใหม่ อย่าเปิดเครื่องภายใน 1 ชั่วโมง</p>

ข้อปฏิบัติในการติดตั้ง

- 1.เดร็งทำบ้าร้อน-เย็น และบ้าเย็น ถูกออกแบบเพื่อใช้ภายในอาคารห้องน้ำ โปรดหลีกเลี่ยงการติดตั้ง บริเวณที่
กลางแจ้ง หรือพื้นที่เปียก และมีความชื้น อย่างเช่น บริเวณใกล้สระน้ำ, ชาน้ำ หรือ ห้องอาบน้ำ
 - 2.เดร็งบ้าร้อน-เย็น และบ้าเย็น ควรติดตั้งบนพื้นที่เรียบ ไม่ลัดเลียง หรือชรุชระเพื่อป้องกันการส่อคลื่นเคลอน
ของตัวเดร็งของจะหัก거나บาน
 - 3.ติดตั้งบริเวณพื้นที่กำลังเทได้สดวก และควรให้มีช่องว่างกำลังเทอากาศจากผับงห้องไปยังด้านหลังของ
ตัวเครื่อง อย่างน้อย 7 นิ้ว
 - 4.เพื่อชัดอาภาริใช้งานของเดร็ง ควรติดตั้งเดร็งในสภาพอากาศที่สะอาดปลอดภัยจากพื้นที่เป็นพิษทางอากาศ
 - 5.โปรดระวังของใช้ติดตั้งสินค้าและสิ่งพลาสติกห่อหุ้มของจากตัวเครื่องให้ขาดรวมมัดระหว่าง
 - 6.ขณะทำการซันเขย่า หรือบรรทุกสินค้า ต้องวางเดร็งในแนวตั้ง ห้ามเอียงเกิน 45 องศา
 - 7.หากทำการเดร็งเขย่าเดร็งใหม่ ควรพักเดร็งไว้อย่างน้อย 1 ชั่วโมง ก่อนการเปิดสวิตช์เดร็งใช้งานในครั้งต่อไป

วิธีการใช้งาน

- ก. ก่อนการใช้งาน ควรทำความสะอาดภายในตัวเครื่อง โดยต้องให้น้ำไหลเวียนไปกลับด้วยตัวเครื่องเรียบร้อย
 - ค. เมื่อต้องการใช้ระบบทำความร้อน-เย็น ต้องมีน้ำจ่ายระบบบ๊าร้อน (เฉพาะรุ่นที่มีระบบบ๊าร้อน) ของตัวเครื่องให้ไหลผ่านได้ โดยสอดคล้องกับเที่ยงเวลาที่ต้องการ ทำการตรวจสอบการทำงานของน้ำส่วนการกรองรักษาไว้ให้โดยตลอดทันทีเมื่อก่อนใช้งาน
 - จ. ควรระวังน้ำลับหรือหออกจนหมดที่ทำลักษณะเดียวกับน้ำลงในปั๊มน้ำ เช่น ไฟฟ้าไม่ต่อต้องได้
 - ฉ. สำหรับรุ่นที่มีระบบบ๊าร้อน จะมีปุ่มสวิตช์ ปิด/เปิด ของปั๊มน้ำร้อนอยู่บริเวณด้านหลังของตัวเครื่อง และกำหนด สัญญาณ (I) หรือ(NO/OF) สำหรับการปิดตัวเครื่องเพื่อใช้งาน
 - ก. การทำงานของระบบทำน้ำเย็นจะดำเนินตัวโดยตัวเองโดยอัตโนมัติ หลังจากจ่ายไฟเข้าตัวเครื่อง ในบางรุ่นจะมีสวิตช์ ปิด/เปิด อยู่ ด้านหลังตัวเครื่อง (รุ่นที่เป็นบ๊าร้อน 1 ก็อค)
 - ข. หลังจากตัวเครื่องเปิดทำงานแล้ว การทำความเย็นจะใช้วремีประมาณ 15-20 นาที และระบบบ๊าร้อนจะใช้วремี ประมาณ 10 นาที

ข้อควรระวัง

1. หันเปิดเตรื่องก่อนเติมน้ำให้ในถัง เมื่อจะการเปิดเตรื่องโดยปราจ加การบรรจุน้ำอาจทำให้อุปกรณ์ของเตรื่องเสียหายได้
 - 2.กรณ์เดีบล๊าชัย หรือเปลี่ยนถังน้ำ ให้ระหว่างน้ำกระดอง หรือหอกออกม้าเพราอาจทำให้ต้องเสียหายถ้าปีกไหรับเชื้อไฟไหม้
 - 3.ก่อนที่จะมีการซ่อมแซมหรือตรวจสอบใดๆ ต้องกอดปลั๊กออกจากแหล่งไฟด้วย
 - 4.ต้องถูกออกแบบมาสำหรับใช้กับน้ำดื่มน้ำที่สะอาดเท่านั้น การใช้น้ำประปาเกลื่นอาจทำให้ต้องเสียหาย หรือหยุดการใช้งานตลอด
 - 5.วิธีการเติมน้ำ
 - 5.1ใช้มือยกที่ัวถัง และมืออีกชั้งหนึ่งจับที่ด่อง
 - 5.2เติมน้ำด้วยความรวดเร็วโดยไม่ให้น้ำสับจากตัวเครื่อง




ข้อแนะนำในการใช้งาน

- ต้องติดตั้งสายดินให้ถูกวิธีพร้อมติดตั้งเครื่องทำน้ำเย็น  
 - ต้องติดตั้งเครื่องป้องกันอันตรายจากไฟร้อน
 - ต้องติดตั้งเครื่องทำน้ำเย็นในบริเวณที่เป็นอนุวนไฟฟ้า และไม่เปียกชื้น เช่น ปูพื้นด้วยยาง ฯลฯ และไม่มีน้ำซึ่นและ
 - ควรตรวจสอบสภาพความปลดตัวของเครื่องทำน้ำเย็นโดยช่างผู้ชำนาญงานเป็นประจำอย่างน้อยทุก 6 เดือน

Technical Information

Model	AD201CH
Voltage - Frequency	220V~50Hz
Heating power	420W
Cooling power	85W
Water Heating capacity	5. 0L/h
Water Cooling capacity	2. 0L/h
Prevention of electric shock	Type I

Circuit Illustration



Note: If technical data or the circuit graphic change, the information sheet may not reflect those changes.

Attention

1. Make sure to have poured water from the hot water faucet before plugging and switching the appliance ON to heat. If the dispenser is turned ON with an empty water tank, it can be damaged.
 2. When you are ready to move the water cooler, do not tilt more than 45° to avoid damage to the compressor.
 3. Always install the dispenser indoors, on a flat surface and at a distance no less than 15 cm from the back wall.
 4. Keep this appliance away from high temperatures and in a dry and ventilated place.
Never install it in the open air or under rain or direct sunlight.
 5. Children should not use the red hot water tap.
 6. If the appliance is not going to be used for a long period of time, unplug it and drain all water in its interior.
 7. Before the first use and after a long period of not using it, the water tank and water pipes should be cleaned well. If possible, they should be disinfected and disinfect, and the first heated water must be discarded (switch the heating switch to OFF while draining the system).
 8. Wash and disinfect the system every 3-6 months with a suitable cleaner and according to its instructions for use.

9. Do not pull out the cable to unplug. Do not turn ON and OFF the appliance by connecting it and disconnecting it from the source of electricity.
10. Do not clean the outside of the appliance with water to avoid electric shock. Clean it with a soft cloth.
11. If you are not using the appliance for a long period of time or during the night, you can turn it OFF to save energy.
12. Do not attempt to change the power cord by yourself if it has any damage. Contact the manufacturer or specialized service personnel.
13. If the power cable suffers any damage, contact the manufacturer, his service representative or qualified personnel.
14. The equipment must be installed keeping easy access to the electrical plug.
15. WARNING - to avoid the risks of an unstable installation, the equipment must be installed following its instructions.
16. WARNING - keep the ventilation openings at the back of the appliance uncovered and unobstructed.
17. NOTICE - do not damage the refrigerant circuit.
18. The environmental temperature for this appliance should be between 18° C and 38 ° C.
19. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and use maintenance shall not be made by children without supervision.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance
- This appliance is intended to be used in household and similar applications such as
- staff kitchen areas in shops, offices and other working environments;
 - farm houses and by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments;
 - catering and similar non-retail applications
20. Do not place other appliances inside this equipment unless those are recommended by the manufacturer.
21. Do not store explosive substances such as spray cans inside this appliance.

What to do in case of problems:

First turn off the water dispenser and disconnect it from the source of electricity.

Problem	Possible cause	How to solve
Lights do not lit	1.Appliance is not connected to the electrical system 2.The switch is not ON	1.Make sure that the switch is ON and the plug is connected 2.Turn the switch into ON or turn the timer
Leaking	1.The water container is broken 2.The water pipe is broken 3.The faucet is damaged	1.Replace the water container 2.Replace the water pipe 3.Replace the faucet
No heating	1.Heating switch is damaged or does not make contact 2.The heating tank is burnt 3.The electrical connection is loose	1.Replace the switch and check the connections 2.Replace heating tank 3.Repair connections
Not cooling	1.Cooling switch is damaged or does not make contact 2.The electrical connection is loose	1.Replace the switch and check the connections 2.Repair connections

This kind of product is used in household and similar environment.

คู่มือการใช้งาน

OPERATION MANUAL

WATER DISPENSER

บาร์โค้ด บาร์โค้ด : AD201CH



NON CFC (เป็นมิตรต่อสิ่งแวดล้อม)



บริษัท เพียวเวลามุน จำกัด เป็นผู้ผลิตและจัดจำหน่าย
เลขที่ 1 ซอยรามคำแหง 199 ถนนรามคำแหง แขวงเมืองบุรี
เขตเมืองบุรี กรุงเทพฯ 10510
โทร.0-2136-7444 โทรสาร 0-2136-7449,0-2136-7450